




OpenSSL

v3.4.1

Integration Guide

u.trust GP HSM

SecurityServer v6.0.0 and v6.1.1

The logo for utimaco, featuring the word "utimaco" in a bold, black, sans-serif font. A small blue diamond is positioned above the letter 'i'. A registered trademark symbol (®) is located to the upper right of the word.

Imprint

Copyright 2026	Utimaco IS GmbH Krefelder Straße 220 52070 Aachen Germany
Phone	AMERICAS +1-844-UTIMACO (+1 844-884-6226) EMEA +49 800-627-3081 APAC +81 800-919-1301
Internet	https://support.hsm.utimaco.com/
e-mail	support@utimaco.com
Document Version	1.0.0
Date	2026-08-11
Status	PUBLISHED
Document No.	IG-2025-0065
All rights reserved	No part of this documentation may be reproduced in any form (printing, photocopy or according to any other process) without the written approval of Utimaco IS GmbH or be processed, reproduced or distributed using electronic systems. Utimaco IS GmbH reserves the right to modify or amend the documentation at any time without prior notice. Utimaco IS GmbH assumes no liability for typographical errors and damages incurred due to them. All trademarks and registered trademarks are the property of their respective owners.

Table of Contents

1	Introduction	5
1.1	About This Guide	5
1.2	Target Audience	5
1.3	Abbreviations	5
1.4	Document Conventions	6
2	Product Overview	8
2.1	OpenSSL	8
2.2	Utimaco u.trust GP HSM	8
3	Integration Requirements and Prerequisites	9
3.1	Tested Versions	9
3.2	Hardware and Software Requirements	10
3.3	Prerequisites	10
4	Installation and Configuration	11
4.1	Setting Up the u.trust GP HSM	11
4.1.1	Installing SecurityServer Software (Linux)	11
4.1.2	Installing SecurityServer Software (Windows)	12
4.2	Setting Up OpenSSL	12
4.2.1	Installing OpenSSL and pkcs11-provider (Linux)	12
4.2.2	Installing OpenSSL and Libp11 (Windows)	14
5	Integration Steps	16
5.1	Configuration on u.trust Anchor	16
5.1.1	Configuration of the PKCS#11 Provider	16
5.1.2	Initializing a PKCS#11 Slot	17
5.2	Configuration on OpenSSL	17
5.2.1	Configuring the OpenSSL Configuration File	17
5.2.2	Verify PKCS#11 Provider	18
6	Verification and Testing	20
6.1	Functional Testing	20
6.1.1	Creating a Key	20
6.1.2	Generate a Certificate from an Existing Key	21
6.1.3	Sign and Verify a Message	22

6.1.4 Encrypt and Decrypt a Message 23

6.1.5 Creating a Local CA 25

6.1.6 Sign a Certificate using the Local CA 28

7 Troubleshooting29

7.1 Common Issues and How to Resolve Them 29

7.2 Log Locations and Interpretation 29

8 Appendices31

8.1 References 31

8.2 Command Summary 31

1 Introduction

This guide is part of the information and support provided by Utimaco. Additional documentation produced to support your Utimaco u.trust GP HSM product can be found in the document directory of the Utimaco u.trust GP HSM product bundle. All Utimaco u.trust GP HSM product documentation is available from Utimaco's web site at <https://utimaco.com/>.

1.1 About This Guide

This guide explains how to integrate an u.trust GP HSM with OpenSSL through the SecurityServer PKCS#11 provider.

1.2 Target Audience

This guide is intended for administrators of OpenSSL and Utimaco HSMs.

1.3 Abbreviations

<i>Abbreviation</i>	<i>Meaning</i>
API	Application Programming Interface
CA	Certificate Authority
CAT	CryptoServer Administration Tool
CD	Compact Disc
CSR	Certificate Signing Request
GUI	Graphical User Interface
HSM	Hardware Security Module

Abbreviation	Meaning
IP	Internet Protocol
LAN	Local Area Network
PCIe	PCI Express Interface
PIN	Personal Identification Number
PKCS#11	Public-Key Cryptography Standard #11
RSA	Rivest-Shamir-Adleman
SO	Security Officer
SSL	Secure Socket Layer
TLS	Transport Layer Security
URL	Uniform Resource Locator

Table 1: List of abbreviations

1.4 Document Conventions

The following conventions are used in this guide:

Convention	Use	Example
Bold	Items of the Graphical User Interface (GUI), e.g., menu options	Press the OK button.

Convention	Use	Example
Monospaced	File names, folder and directory names, commands, file outputs, programming code samples	You will find the file <code>example.conf</code> in the <code>/exmp/demo/</code> directory.
<i>Italic</i>	References and important terms	See Chapter 3, "Sample Chapter", in the <i>u.trust Anchor - csadm Manual</i> or [CSADM] .

Table 2: Document conventions

Special icons are used to highlight the most important notes and information.



This message marks the result expected after the successful execution of an instruction.



Here you find additional notes or supplementary information.



Here you find important safety information that should be followed.

2 Product Overview

2.1 OpenSSL

OpenSSL is an open-source tool for using the Secure Socket Layer (SSL) and Transport Layer Security (TLS) protocols for Web Authentication. It offers cryptographic functions to support SSL/TLS protocols.

It allows users to perform various SSL-related tasks, including CSR (Certificate Signing Request) and private key generation, as well as SSL certificate installation. Most of the Linux distributions come with pre-compiled OpenSSL, but if you are on a Windows system, you can get it through manual installation.

OpenSSL has an abstraction layer called providers, which can delegate cryptographic operations to different pieces of software or hardware.

The pkcs11-provider provides an OpenSSL plugin that tries to fit the PKCS#11 API within the OpenSSL provider API. That is, it provides a gateway between PKCS#11 modules and the OpenSSL provider API.

2.2 Utimaco u.trust GP HSM

The u.trust GP HSM is a next-generation hardware security module developed by Utimaco IS GmbH. It is a multi-tenant, physically protected, and tamper-resistant cryptographic appliance designed to perform high-assurance cryptographic operations and manage cryptographic keys securely. The u.trust GP HSM is built on a modern, container-based design inspired by cloud technology. With support for up to 31 containers and multiple PKCS #11 partitions per cHSM, it ensures seamless application separation and key partitioning, making it an ideal choice for all types of cryptographic applications. It's also upgradeable for specific use cases like blockchain and 5G, and offers flexibility for custom solutions, including proprietary algorithms and customer key derivations via the Software Development Kit.

3 Integration Requirements and Prerequisites

Ensure that the system environment you will be using meets the following hardware and software requirements.

This guide assumes that the user has already installed and configured the required software.

3.1 Tested Versions

The integrations that have been successfully tested with the Utimaco HSM with OpenSSL:

<i>Operating System</i>	<i>OpenSSL</i>	<i>Utimaco u.trust Anchor cHSM Version</i>	<i>Utimaco HSM</i>
RHEL 9	OpenSSL 3.4.1	u.trust Anchor cHSM 6.0.0 and 6.1.1	u.trust GP HSM
RHEL 10	OpenSSL 3.4.1	u.trust Anchor cHSM 6.0.0 and 6.1.1	u.trust GP HSM
Ubuntu 24.04	OpenSSL 3.4.1	u.trust Anchor cHSM 6.0.0 and 6.1.1	u.trust GP HSM
Ubuntu 22.04	OpenSSL 3.4.1	u.trust Anchor cHSM 6.0.0 and 6.1.1	u.trust GP HSM
Windows Server 2022	OpenSSL 3.4.1	u.trust Anchor cHSM 6.0.0 and 6.1.1	u.trust GP HSM

Table 3: List of tested versions

3.2 Hardware and Software Requirements

Hardware	Hardware Requirements
Utimaco u.trust Anchor LAN HSM	u.trust GP HSM available with firmware SecurityServer 6.0.0 and 6.1.1

Table 4: List of hardware requirements

Software	Software Requirements
OpenSSL	OpenSSL 3.4.1
pkcs11-provider (Linux)	1.1.0
Libp11 (Windows)	0.4.14
HSM Interface	SecurityServer PKCS#11 Provider

Table 5: List of software requirements

3.3 Prerequisites

Before you begin, please ensure that you have:

- A u.trust GP HSM setup and configured. Refer to the u.trust GP HSM documentation to set up the HSM.
- An MBK created and stored on each cHSM. Refer to the u.trust GP HSM documentation to set up the MBK.
- The HSM Default Admin replaced with a new admin user for production environments.
- An operating system listed in [Tested Versions](#).
- A u.trust GP HSM version listed in [Tested Versions](#).
- Familiarized yourself with the OpenSSL documents and setup process.

4 Installation and Configuration

4.1 Setting Up the u.trust GP HSM

If you have not already done so, please create and request an Utimaco Support Portal Account. This will allow you to download the software components needed for this installation.

If you have purchased an HSM from Utimaco, you will need the associated product bundle containing the required Windows or Linux software packages. This bundle can be downloaded from the Utimaco Support Portal. Please ensure you request access to the product bundle beforehand through the support portal.

4.1.1 Installing SecurityServer Software (Linux)

To install the SecurityServer software on a Linux system, complete the following steps:

1. Copy the downloaded software to the appropriate location on the OpenSSL Server.
2. Create an utimaco folder under /opt directory and further create two directories: `/opt/utimaco/bin` and `/opt/utimaco/lib`.

>_ Console

```
mkdir -p /opt/utimaco/bin  
mkdir -p /opt/utimaco/lib
```

3. Copy the pkcs11 library file `libcs_pkcs11_R3.so` from the Utimaco SecurityServer software to the `/opt/utimaco/lib` directory.

>_ Console

```
cp ./u.trust_anchor_product_bundle-x.x.x/Software/Linux/Crypto_APIs/PKCS11_R3//  
lib/libcs_pkcs11_R3.so /opt/utimaco/lib
```

4. Copy the `csadm` and `p11tool2` files from the Utimaco SecurityServer software to the `/opt/utimaco/bin` directory and make both the files executable.

›_ Console

```
cd ./u.trust_anchor_product_bundle-x.x.x/Software/Linux/Administration
cp csadm p11tool2 /opt/utimaco/bin
chmod +x /opt/utimaco/bin/csadm /opt/utimaco/bin/p11tool2
```

4.1.2 Installing SecurityServer Software (Windows)

Install the latest version of the SecurityServer software following the instructions provided in the *Setup* section of the *u.trust Anchor - Administration Manual* [UTAADMIN]. For integration with OpenSSL, only the PKCS#11 Application Interface is required, as well as the administration tools.

4.2 Setting Up OpenSSL

4.2.1 Installing OpenSSL and pkcs11-provider (Linux)



If you are using an existing or pre-installed OpenSSL, then skip the first two steps.

1. Install the necessary dependencies.

›_ Console

```
dnf -y update && \
dnf install -y make gcc wget tar git autoconf automake libtool \
perl-IPC-Cmd perl-core perl-Test-Harness perl-Data-Dumper \
which findutils diffutils xz meson \
openssl-devel
```

2. Install OpenSSL.

>_ Console

```
# From the SO repository
dnf install openssl
# From the official source
cd /tmp
wget https://www.openssl.org/source/openssl-3.4.1.tar.gz && \
    tar -xzvf openssl-3.4.1.tar.gz && \
    cd openssl-3.4.1 && \
    ./Configure linux-x86_64 --prefix=/usr/local/openssl-3.4.1 shared && \
    make -j$(nproc) && \
    make install_sw && \
    cd .. && rm -rf openssl-3.4.1
```

3. Verify the version of OpenSSL.

>_ Console

```
openssl version
OpenSSL 3.4.1 11 Feb 2025 (Library: OpenSSL 3.4.1 11 Feb 2025)
```

4. Install the pkcs11-provider from the official source.

>_ Console

```
cd /tmp
wget https://github.com/latchset/pkcs11-provider/releases/download/v1.1.0/
pkcs11-provider-1.1.tar.xz && \
    tar -xJvf pkcs11-provider-1.1.tar.xz && \
    cd pkcs11-provider-1.1 && \
    PKG_CONFIG_PATH=/usr/local/openssl-3.4.1/lib64/pkgconfig meson setup
buildidir && \
    meson compile -C buildidir && \
    meson install -C buildidir && \
    cd .. && rm -rf pkcs11-provider-1.1*
```

5. Adjust the environment variables.

>_ Console

```
export PATH="/usr/local/openssl-3.4.1/bin:${PATH}"
export LD_LIBRARY_PATH="/usr/local/openssl-3.4.1/lib64:\
/usr/local/openssl-3.4.1/lib64/ssl-modules:${LD_LIBRARY_PATH}"
```



To ensure these environmental variables are set after a reboot, the last commands should be added to `~/.bashrc`.

4.2.2 Installing OpenSSL and Libp11 (Windows)

1. Download and install OpenSSL; refer to the [OpenSSL for Windows release page](#) to obtain the OpenSSL installer.
2. Add the OpenSSL `bin/` directory to the system `PATH`.
3. Verify the OpenSSL version using the following command in a terminal.

>_ Console

```
openssl version  
OpenSSL 3.4.1 11 Feb 2025 (Library: OpenSSL 3.4.1 11 Feb 2025)
```

4. Download libp11 from the [official libp11 release page](#) and extract its content.
5. Verify that pkcs11.dll is available inside the `<libp11>/` folder.

5 Integration Steps

5.1 Configuration on u.trust Anchor

5.1.1 Configuration of the PKCS#11 Provider

1. Create the directory `/etc/utimaco`.
2. Locate the Utimaco PKCS#11 configuration file in your SecurityServer directory, `./u.trust_anchor_product_bundle-x.x.x/Software/Linux/Crypto_APIS/PKCS11_R3/sample`. Copy the Utimaco PKCS#11 configuration file `cs_pkcs11_R3.cfg` into the `/etc/utimaco` directory.
3. Edit the `cs_pkcs11_R3.cfg` file and make the appropriate changes to the file.



cs_pkcs11_R3.cfg

```
[Global]

# For unix:
Logpath = /tmp

# Loglevel (0 = NONE; 1 = ERROR; 2 = WARNING; 3 = INFO; 4 = TRACE)
Logging = 1
Keepalive = false

# Set the Device to connect with the HSM

# Device specifier
Device = <PORT@IP>
```



For more information regarding the commands and command parameters, please check the Utimaco u.trust GP HSM documentation. The device will be either a PCIe or LAN device. The device line will follow one of the following patterns, based on the HSM form factor:

Device = 4001@<HSM IP address> Hardware (LAN) HSM

or

Device = /dev/cs2.0 Hardware (PCIe) HSM



To make your testing easier, enable the PKCS#11 log file. You can enable it by editing the Logging Loglevel. Set the LogPath and Logging Loglevel to 1. For testing, you may want to increase them to 4.

The added LogPath points to a writable directory, not to a file.

If you encounter problems, check the log file named cs_pkcs11_R3.log in the LogPath-defined directory. When you are done testing, change the Logging to 1 or 2. This will limit the logging to only critical and important messages.

4. Set up the `CS_PKCS11_R3_CFG` environment variable.

```
export CS_PKCS11_R3_CFG=/etc/utimaco/cs_pkcs11_R3.cfg
```

5.1.2 Initializing a PKCS#11 Slot

You must initialize a slot with a custom label using p11tool2.

Using the following commands, the Security Officer and User will be initialized.

```
./p11tool2 slot=<slot_no> Label=<token_label> Login=ADMIN,ADMIN.key InitToken=ask  
./p11tool2 slot=<slot_no> LoginSO=ask InitPin=ask
```

5.2 Configuration on OpenSSL

5.2.1 Configuring the OpenSSL Configuration File

1. Open the file `/etc/pki/tls/openssl.cnf` on Linux or `C:\Program Files\Common Files\SSL\openssl.cnf` on Windows and enter the following line in the first line of the file.

>_ Console

```
openssl_conf = openssl_init
```

2. Enter the following lines under the last section of the `openssl.cnf` file.

>_ openssl.cnf

```
[openssl_init]
providers=provider_sect

[provider_sect]
default = default_sect
pkcs11 = pkcs11_sect

[default_sect]
activate = 1

[pkcs11_sect]
module = /usr/lib/x86_64-linux-gnu/openssl-modules/pkcs11.so
pkcs11-module-path = /opt/utimaco/lib/libcs_pkcs11_R3.so
pkcs11-module-login-behavior = always
activate = 1
```



The dynamic path and module path will be changed according to the user environment.

On Linux, `dynamic_path` must point to `pkcs11.so`. On Windows, it must point to `pkcs11.dll`.

In both environments, `dynamic_path` must point to the SecurityServer PKCS#11 provider.

5.2.2 Verify PKCS#11 Provider

Run the command below to verify if the OpenSSL Provider is available.

>_ Console

```
openssl list -providers
Providers:
  default
    name: OpenSSL Default Provider
    version: 3.4.1
    status: active
  pkcs11
    name: PKCS#11 Provider
    version: 1.1
    status: active
```

6 Verification and Testing

6.1 Functional Testing

This section describes common cryptographic procedures for testing the integration between the OpenSSL PKCS#11 provider and the Utimaco HSM.

All the commands are written for a Linux environment. To execute them in a Windows environment, please adjust the paths to their Windows equivalent.

6.1.1 Creating a Key

1. Generate the key using p11tool2.

>_ Console

```
# For RSA
p11tool2 slot=<SLOT_NUMBER> LoginUser=ask PubKeyAttr=CKA_LABEL="CertKey"
PrvKeyAttr=CKA_LABEL="CertKey" GenerateKeyPair=RSA

# For ECC
p11tool2 slot=<SLOT_NUMBER> LoginUser=ask PubKeyAttr=CKA_LABEL="TestECDSAKey"
PrvKeyAttr=CKA_LABEL="TestECDSAKey",CKA_DERIVE=CK_TRUE GenerateKeyPair=ECC
```



The PKCS#11 PIN can be directly introduced in the `LoginUser` parameter, but this will be stored in plain text in the command history.

2. Verify that the keys are generated onto the HSM using the following command:

>_ Console

```
p11tool2 LoginUser=ask ListObjects
CKO_PUBLIC_KEY:
+ 1.1
  CKA_KEY_TYPE           = CKK_RSA
  CKA_UNIQUE_ID          = C92DB9A3-9D2C-4DB7-B217-EDC44BB5966C
  CKA_LABEL              = CertKey
  CKA_ID                 =
+ 1.2
  CKA_KEY_TYPE           = CKK_ECDSA
  CKA_UNIQUE_ID          = 3B4C290B-46FE-4F66-8E95-C7771A112A45
  CKA_LABEL              = TestECDSAKey
  CKA_ID                 =
CKO_PRIVATE_KEY:
+ 2.1
  CKA_KEY_TYPE           = CKK_RSA
  CKA_UNIQUE_ID          = 02F66F14-0BB7-45B9-9100-74CDF5F71F46
  CKA_SENSITIVE          = CK_TRUE
  CKA_EXTRACTABLE        = CK_FALSE
  CKA_LABEL              = CertKey
  CKA_ID                 =
+ 2.2
  CKA_KEY_TYPE           = CKK_ECDSA
  CKA_UNIQUE_ID          = 6153C311-91E7-4CA5-875A-8CC43DF36732
  CKA_SENSITIVE          = CK_TRUE
  CKA_EXTRACTABLE        = CK_FALSE
  CKA_LABEL              = TestECDSAKey
  CKA_ID                 =
```

6.1.2 Generate a Certificate from an Existing Key

1. Obtain the key label using p11tool2.

>_ Console

```
p11tool2 LoginUser=ask ListObjects
```

2. Generate a Certificate Signing Request (CSR).

>_ Console

```
openssl req -new -key "pkcs11:token=<token_label>;object=<key_label>" -out TestRSACSR.csr
```

Here, `key_label` is the key label on the HSM. Provide the CryptoUser PIN and certificate details when prompted.

3. Create the self-signed certificate based on the generated key.

>_ Console

```
openssl req -new -x509 -days 365 -key  
"pkcs11:token=<token_label>;object=<key_label>" -out Test.cert
```

6.1.3 Sign and Verify a Message

1. Create a sample text file with any content inside it.

>_ Console

```
echo "Sample message" > message.txt
```

2. Sign the message file.

>_ Console

```
openssl cms -sign -in message.txt -signer TestRSA.cert -inkey  
"pkcs11:token=<token_label>;object=<key_label>" -out signedRSAMessage.txt
```

The result will be a signed message with the following format.

›_ Signed Message

```
MIME-Version: 1.0
Content-Type: multipart/signed; protocol="application/pkcs7-signature";
micalg="sha-256"; boundary="----4483E8F5EBA4258E73C09280E53170FE"
```

This is an S/MIME signed message

-----4483E8F5EBA4258E73C09280E53170FE

Sample Message

-----4483E8F5EBA4258E73C09280E53170FE

Content-Type: application/pkcs7-signature; name="smime.p7s"

Content-Transfer-Encoding: base64

Content-Disposition: attachment; filename="smime.p7s"

MIIGFgYJKoZIhvcNAQcCoIIGBzCCBgMCAQExDTALBglghkgBZQMEAgEwCwYJKoZI

...

EwOn9N1Fh/Y+f4B4zkan/JvlsuCUhma630BdmQm03SGGvyWfkdN/lpLCP2zGPwAZ

Jl8M/QyBddmJJHvy/K5zRrxHmkpEDhvYwf0=

-----4483E8F5EBA4258E73C09280E53170FE--

3. Verify the signature of the message.

›_ Console

```
openssl cms -verify -noverify -in signedRSAMessage.txt -CAfile TestRSA.cert -out
originalmessage.txt TestRSA.cert
Warning: recipient certificate file parameters ignored for operation other than
-encrypt
Sample Message
CMS Verification successful
```

6.1.4 Encrypt and Decrypt a Message

1. Encrypt the message using the following command:

>_ Console

```
openssl cms -encrypt -in signedRSAmessage.txt -out encryptedRSAsignedmessage.txt  
TestRSA.cert
```

The encrypted message will have the following format:

>_ Encrypted Message

```
MIME-Version: 1.0  
Content-Disposition: attachment; filename="smime.p7m"  
Content-Type: application/pkcs7-mime; smime-type=enveloped-data;  
name="smime.p7m"  
Content-Transfer-Encoding: base64  
  
MIIMFAYJKoZIhvcNAQcDoIIMBTCCDAECAQAxggF5MIIBdQIBADBdMEUxCzAJBgNV  
BAYTAkFVMRMwEQYDVQQIDApTb211LVN0YXR1MSEwHwYDVQQKDBhJbnR1cm5ldCBX  
aWRnaXRzIFB0eSBMdGQCFAdGmeMIYrV4twsA8FLt3ZBvn5vdMA0GCSqGSIb3DQEB  
...  
4QTULf9IDxS7/pxXb0P63ij+jIPB8WRD5hm6uYna/niWxMlEfFlwyBSEK+5VtIRT  
z5jrZEplI7a3qsdCYPICWSQWn5oxg1L7uskWBBtwyFrMGHIC9BtMx3wNATix9Ni7  
HUoc0oXZyWhjn4jKqdmj2bSrfrk2BqU5I
```

2. Decrypt the message with the following command:

>_ Console

```
openssl cms -decrypt -in encryptedRSAsignedmessage.txt -inkey  
"pkcs11:token=<token_label>;object=<key_label>" -out  
decryptedRSAsignedmessage.txt
```

6.1.5 Creating a Local CA

1. Open the `/<OPENSSLDIR>/openssl.cnf` file in the text editor and edit the `[CA_default]` section to following:

openssl.cnf

```
dir = /localCA
new_certs_dir = $dir/newcerts
```



You can change `dir` to the directory of your choice, but make sure to use the correct path in the subsequent steps. Here, we have created directory `/localCA` under the root directory, and `new_certs_dir = $dir/newcerts`.

2. Create the directory `/localCA/newcerts`.

>_ Console

```
mkdir /localCA/newcerts
```

3. Create the text files `/localCA/index.txt` and `/localCA/serial`.

>_ Console

```
touch /localCA/index.txt
echo "01" > /localCA/serial
```

4. Create a key pair by using `p11tool2` for root CA.

>_ Console

```
# For RSA
p11tool2 slot=<SLOT_NUMBER> LoginUser=ask PubKeyAttr=CKA_LABEL="CAKey"
PrvKeyAttr=CKA_LABEL="CAKey" GenerateKeyPair=RSA
# This generates RSA 2048 CA private and public keys on the HSM
# For ECC
p11tool2 slot=<SLOT_NUMBER> LoginUser=ask PubKeyAttr=CKA_LABEL="CAKey"
PrvKeyAttr=CKA_LABEL="CAKey" GenerateKeyPair=ECC
# This generates ECC CA private and public keys on the HSM
```

5. Verify that the keys are generated onto the HSM using the following command:

>_ Console

```
p11tool2 Slot=<SLOT_NUMBER> LoginUser=ask ListObjects
```

```
CKO_PUBLIC_KEY:
```

```
+ 1.1
```

```
CKA_KEY_TYPE          = CKK_RSA
CKA_UNIQUE_ID          = C92DB9A3-9D2C-4DB7-B217-EDC44BB5966C
CKA_LABEL              = CAKey
CKA_ID                 =
```

```
+ 1.2
```

```
CKA_KEY_TYPE          = CKK_ECDSA
CKA_UNIQUE_ID          = 3B4C290B-46FE-4F66-8E95-C7771A112A45
CKA_LABEL              = CAKeyECC
CKA_ID                 =
```

```
CKO_PRIVATE_KEY:
```

```
+ 2.1
```

```
CKA_KEY_TYPE          = CKK_RSA
CKA_UNIQUE_ID          = 02F66F14-0BB7-45B9-9100-74CDF5F71F46
CKA_SENSITIVE          = CK_TRUE
CKA_EXTRACTABLE        = CK_FALSE
CKA_LABEL              = CAKey
CKA_ID                 =
```

```
+ 2.2
```

```
CKA_KEY_TYPE          = CKK_ECDSA
CKA_UNIQUE_ID          = 6153C311-91E7-4CA5-875A-8CC43DF36732
CKA_SENSITIVE          = CK_TRUE
CKA_EXTRACTABLE        = CK_FALSE
CKA_LABEL              = CAKeyECC
CKA_ID                 =
```

6. Create the CA certificate based on the generated key that is used for signing other certificates by running the command below.

```
>_ Console
```

```
openssl req -new -x509 -days 365 -key "pkcs11:token=<token_name>;object=CAKey"
-out /localCA/newcerts/ca.cer
```

Here, `CAKey` is the `Object Label` for the CA private key on the Utimaco HSM created in Step 5, and `<token_name>` is the token label. Provide the CryptoUser PIN when prompted.

6.1.6 Sign a Certificate using the Local CA

1. Generate a key pair using `p11tool2`.

>_ Console

```
# For RSA
p11tool2 slot=<slot_No.> LoginUser=ask PubKeyAttr=CKA_LABEL="<key_label>"
PrvKeyAttr=CKA_LABEL="<key_label>" GenerateKeyPair=RSA
# This generates RSA 2048 private and public keys on the HSM
# For ECC
p11tool2 slot=<slot_No.> LoginUser=ask PubKeyAttr=CKA_LABEL="<key_label>"
PrvKeyAttr=CKA_LABEL="<key_label>" GenerateKeyPair=ECC
# This generates ECC private and public keys on the HSM
```

2. Generate a certificate request.

>_ Console

```
openssl req -new -key "pkcs11:token=<token_label>;object=<key_label>" -out /
localCA/newcerts/request.csr
```

3. Sign the certificate request for sender by CA.

>_ Console

```
openssl ca -policy policy_anything -cert /localCA/newcerts/ca.cer -in /localCA/
newcerts/request.csr -keyfile "pkcs11:token=<token_label>;object=<key_label>"
-out /localCA/newcerts/certificate.crt
```

7 Troubleshooting

7.1 Common Issues and How to Resolve Them

Error	Diagnosis
The private key was not found at: pkcs11:token=FedoraCert;object= CertKey1 PKCS11_get_private_key returned NULL Could not read private key from org.openssl.engine:pkcs11:pkcs11:token=FedoraCert;object= CertKey1	Check that the Key exists on the slot and provide the correct key name.
11.01.2023 11:18:37.059 [00016138:00016138] open_plugin W: HSM::ConnectionException(Error::NO_DEVICE_AVAILABLE = 0xbe000007) thrown in select_device Error::NO_DEVICE_AVAILABLE	Make the changes in the key storage section in the cs_pkcs11.cfg file and check that the HSM device is running and reachable from the host.
20.06.2025 07:56:39: C_OpenSession returned Error 0x00000005 (CKR_GENERAL_ERROR)	Check the PKCS#11 log (/tmp/cs_pkcs11_R3.log by default) for errors. If it doesn't exist or doesn't get updated, check if the CS_PKCS11_R3_CFG environment variable is set with the location of the PKCS#11 configuration file.

Table 6: List of errors and their diagnoses

7.2 Log Locations and Interpretation

The following logs can be reviewed to check for errors:

- Utimaco PKCS#11 provider log: /tmp/cs_pkcs11_R3.log by default, configured in the PKCS#11 configuration file.

- This log contains all the PKCS#11 function calls and attributes.

Error	Diagnosis
<pre>20.06.2025 07:51:25.108 [00000332:00000332] C_OpenSession E: HSM::ConnectionException(Error:: NO_CONNECTION = 0xbe000015) thrown in open_session Error::NO_CONNECTION</pre>	The provider couldn't connect to the HSM. Please check the PKCS#11 configuration file and ensure the Device section is correctly configured. See Configuration of the PKCS#11 Provider for details.
<pre>20.06.2025 07:10:30.866 [00000059:00000059] C_GetSlotInfo E: Error CKR_DEVICE_REMOVED occurred.</pre>	The device was disconnected during the cryptographic operation. This probably happens because of connection issues.

Table 7: List of common errors on the PKCS#11 Log File

8 Appendices

8.1 References

Reference	Title	Document Number
[CSADM]	u.trust Anchor – csadm Manual / Utimaco IS GmbH	2021-0037
[UTAADMIN]	u.trust Anchor - Administration Manual / Utimaco IS GmbH	2020-0035
[UTAP11Tool 2]	u.trust Anchor - PKCS#11 p11tool2 Reference Manual / Utimaco IS GmbH	2021-0072

Table 8: References

8.2 Command Summary

Task	Command
Create an RSA Key	<pre>p11tool2 slot=\$PKCS11_SLOT LoginUser=\$PKCS11_PIN PubKeyAttr=CKA_LABEL=\$KEY_LABEL PrvKeyAttr=CKA_LABEL=\$KEY_LABEL GenerateKeyPair=RSA</pre>
Create an ECC Key	<pre>p11tool2 slot=\$PKCS11_SLOT LoginUser=\$PKCS11_PIN PubKeyAttr=CKA_LABEL=\$KEY_LABEL PrvKeyAttr=CKA_LABEL=\$KEY_LABEL GenerateKeyPair=RSA</pre>
Generate a Certificate Signing Request from a key	<pre>openssl req -new -key "pkcs11:token=\$PKCS11_TOKEN;object=\$KEY_LABEL;pin- value=\$PKCS11_PIN" [-subj "/CN=.../"] -out test.csr</pre>

Task	Command
Generate a certificate from a Certificate Signing Request	<pre>openssl req -new -x509 -days 365 -key "pkcs11:token=\$PKCS11_TOKEN;object=\$KEY_LABEL;pin- value=\$PKCS11_PIN" -subj "/CN=.../" -out test.cert</pre>
Generate an encrypted message from a file using a certificate	<pre>openssl cms -encrypt -in message.txt -out encrypted_message.txt test.cert</pre>
Decrypt an encrypted message using a private key	<pre>openssl cms -decrypt -in encrypted_message.txt -inkey "pkcs11:token=\$PKCS11_TOKEN;object=\$KEY_LABEL;pin- value=\$PKCS11_PIN" -out decrypted_message.txt</pre>
Generate a signed message from a file using a private key	<pre>openssl cms -sign -in message.txt -signer test.cert -inkey "pkcs11:token=\$PKCS11_TOKEN;object=\$KEY_LABEL;pin- value=\$PKCS11_PIN" -out signed_message.txt</pre>
Verify a signed message using a certificate	<pre>openssl cms -verify -noverify -in signed_message.txt -CAfile test.cert -out verified_message.txt</pre>
Generate a CA from a private key	<pre>openssl req -new -x509 -days 365 -key "pkcs11:token=\$PKCS11_TOKEN;object=\$KEY_LABEL;pin- value=\$PKCS11_PIN" -subj "/CN=.../" -out ca.cer</pre>
Sign a Certificate Signing Request using a CA private key	<pre>openssl ca -batch -policy policy_anything -cert ca.cer -in request.csr -keyfile "pkcs11:token=\$PKCS11_TOKEN;object=\$KEY_LABEL;pin- value=\$PKCS11_PIN" -out certificate.crt</pre>

Table 9: List of Commands